




Wind Speed Sensor 2740/2740EX

A sensor for measuring the average and maximum wind speed (gust) during the sampling interval. The sensor is designed for use with Aanderaa Dataloggers 3634/3660 and the Aanderaa Automatic Weather Station 2700.

Features:

- Low power
- Low threshold speed
- High maximum speed
- User friendly
- SR10 output format



The Wind Speed Sensor 2740 consists of a three cup rotor on top of an aluminium housing. The sensor can be fitted directly onto the Sensor Cross Arms 3415/3435 of an Aanderaa automatic weather station or used separately if a connecting cable is used. The sensor foot will fit onto a 25 mm vertical tube.

The rotor bearing assembly consist of two stainless steel ball bearings in an assembly protected by a surrounding skirt. The lower end of the skirt is furnished with a magnet, and the magnet's rotation is sensed by a magneto inductive switch located inside the housing.


A micro controller reads the pulses from the magneto inductive switch sensing the rotor's rotation and uses the pulse count to calculate the wind speed. The sensor has two output signals; average wind speed and maximum wind speed (gust) during the sampling interval.

The average wind speed is obtained as the arithmetic mean of the wind regardless of the sampling interval, provided that the sampling interval is between four seconds and three hours.

The maximum wind speed is the highest speed occurring over a two-second period at any time during the sampling interval.

The micro controller also provides the Aanderaa SR10 output signals for wind speed and gust. Both output signals will have the same conversion factor for calculation of wind speed in engineering units from the ten-bit output data. This factor is independent of the sampling interval used.

From august 1998 the sensor has been supplied with a new and more rugged three-cup rotor designated 2228A.




- Range:** Up to 79m/s
- Threshold speed:** Less than 0.3m/s
- Distance constant:** 1.5 m
- Accuracy:** ±2% or ±0.2m/s, whichever is greater
- Output signals:** 1. Average wind speed, SR10
2. Wind gust, SR10
- Current consumption:** 300 µA
- Operating voltage:** 7 to 14V DC, obtained from Datalogger
- Calibration factor:** 1.194 m wind way for each rev.
2 counts each rotor revolution
- Operating temp.:** -40 to +65°C
- Electrical connection:** Receptacle 2843 mating Sensor Cross Arms 3415/3435 or Watertight Plug 2828L
- Material housing:** Al 6061-T6, anodized 10-15µ
- Net weight:** 500g
- Packing:** Cardboard box, 385x290x235mm
- Gross weight:** 1.3 kg, (add 0.7 kg for 10m Connecting Cable 2842)
- Approvals:** certified CE

The sensor is available as an  certified sensor; contact factory for prices

- Accessories, not included:**
- Gust Adapter Cable 2911
 - Connecting Cable 2842
 - Sensor Cable 3321/3322/3323
 - Connecting Cable 3576
 - Sensor Bracket 2808/33314/3494

PIN CONFIGURATION



CALIBRATION

Serial No:

The wind speed sensor has nominal calibration coefficients.

The coefficients are:

A	0	C	0
B	7.770E-02	D	0

The raw data readings (N) from the sensor are converted to engineering units by the following formula:

$$\text{Wind (m/s)} = A + BN + CN^2 + DN^3$$

For previously supplied wind speed sensors with the old Three-Cup Rotor 2228 the coefficients are:
A = 4.000 E-01 B = 7.460 E-02 C and D = 0



Visit our Web site for the latest version of this document and more information

www.aanderaa.com

Aanderaa Data Instruments AS
Sanddalsringen 5b, Postboks 103 Midtun,
5828 Bergen, Norway
Tel +47 55 60 48 00
Fax +47 55 60 48 01